


VIRTUAL USB DRIVER



The screenshot shows a software window titled 'PTZ Virtual USB Driver' with a table of camera configurations. The table has columns for No., Camera Title, Model, IP Address, Status, Stream Setting, and Video Format. There are five rows of data, with the first three cameras being online and the last two being offline.

No.	Camera Title	Model	IP Address	Status	Stream Setting	Video Format
1	AIR-UN70	CAM-UN70	192.168.0.10	ONLINE	H.264(T)	1920x1080 / 60 fps
2	AIR-HE130	CAM-HE130	192.168.0.12	ONLINE	H.264(T)	1920x1080 / 60 fps
3	AIR-HE70	CAM-HE70	192.168.0.20	ONLINE	H.264(T)	1920x1080 / 60 fps
4			192.168.0.30	OFFLINE		
5			192.168.0.40	OFFLINE		

PTZ Virtual USB Driver is an application software that runs on Windows. This makes it possible to use a remote camera in a network as a USB camera

PTZ Virtual USB Driver

Software that converts PTZ camera on your network into Super Web cam PTZ Virtual USB Driver (Free software)

Key Features

Able to use PTZ cameras on the network as USB cameras

Up to 5 cameras can be registered

Automatic camera discovery and network setting

PTZ Virtual USB
Driver

<https://oc.connect.panasonic.com/nz/en/products/broadcast-proav/ptz-virtual-usb-driver>