

List of Compatible Device Models

Multi Monitoring & Control Software 4.0

- As of October 2024 -

In using this software, bear in mind that the items whose settings must be selected for the projectors and the functions that can be used may differ from one projector model to another. While referring to the table below, check out that projector models are compatible with the software before using them.

■ A list of compatible flat panel display models is available for download from the Panasonic website (<https://docs.connect.panasonic.com/prodisplays/download/software>).

List of device models

■ Projector*1

NTN91000*2	71	PT-DW7000*3	40
NTN91001*2	71	PT-DW730	37
NTN91002*2	70	PT-DW740	36
NTN91003*2	70	PT-DW750	22
PT-CMZ50	27	PT-DW830	22
PT-D10000*3	39	PT-DW8300	35
PT-D12000	34	PT-DW90XE*3	35
PT-D3500*3	41	PT-DX100	22
PT-D4000	41	PT-DX500	38
PT-D5000	37	PT-DX610	36
PT-D5600*3	41	PT-DX800	37
PT-D5700	41	PT-DX810	36
PT-D6000	37	PT-DX820	22
PT-D7700*3	40	PT-DZ10K	21
PT-DS100XE*3	35	PT-DZ110XE*3	35
PT-DS12K	21	PT-DZ12000	34
PT-DS20K	21	PT-DZ13K	21
PT-DS20K2	20	PT-DZ16K	21
PT-DS8500	35	PT-DZ16K2	20
PT-DW100	34	PT-DZ21K	21
PT-DW10000*3	39	PT-DZ21K2	20
PT-DW105XEA*4	35	PT-DZ570	38
PT-DW11K	21	PT-DZ6700	37
PT-DW17K	21	PT-DZ6710	37
PT-DW17K2	20	PT-DZ680	36
PT-DW5000*3	41	PT-DZ770	36
PT-DW5100	41	PT-DZ780	22
PT-DW530	38	PT-DZ870	22
PT-DW6300	37	PT-DZ8700	35
PT-DW640	36	PT-EW530	45

PT-EW540	42	PT-LB332*4	65
PT-EW550	43	PT-LB353*4	65
PT-EW551*4	44	PT-LB355*4	64
PT-EW630	45	PT-LB356*4	63
PT-EW640	42	PT-LB360	66
PT-EW650	43	PT-LB382	65
PT-EW651*4	44	PT-LB383	65
PT-EW730	42	PT-LB385*4	64
PT-EX12K	46	PT-LB386*4	63
PT-EX16K	46	PT-LB412	65
PT-EX500	45	PT-LB423	65
PT-EX510*4	42	PT-LB425	64
PT-EX520*4	43	PT-LB426	63
PT-EX521*4	44	PT-LB90NT	68
PT-EX600	45	PT-LMW420	28
PT-EX610	42	PT-LMW460	28
PT-EX620	43	PT-LMX420	28
PT-EX621*4	44	PT-LMX460	28
PT-EX800	42	PT-LMZ420	28
PT-EZ57*4	43	PT-LMZ460	28
PT-EZ570	45	PT-LRW35*4	62
PT-EZ580	42	PT-LRZ35*4	62
PT-EZ590	43	PT-LW25H	67
PT-EZ591*4	44	PT-LW280	66
PT-EZ770	42	PT-LW312	65
PT-F100NT	60	PT-LW330	66
PT-F200NT	60	PT-LW333*4	65
PT-F300	59	PT-LW335*4	64
PT-F300NT	59	PT-LW336*4	63
PT-FRQ50	18	PT-LW362	65
PT-FRQ60	18	PT-LW373	65
PT-FRZ50	19	PT-LW375	64
PT-FRZ55	19	PT-LW376	63
PT-FRZ60*4	19	PT-LX26H	67
PT-FW100NT	60	PT-LX30H	67
PT-FW300	59	PT-LZ370	61
PT-FW300NT	59	PT-MW530	26
PT-FW430	58	PT-MW630	26
PT-FW530	44	PT-MW730	26
PT-FX400	58	PT-MZ10K	24
PT-FX500*4	44	PT-MZ11K	23
PT-FZ570	44	PT-MZ13K	24
PT-JW130F*4	71	PT-MZ14K	23
PT-JW130G*4	71	PT-MZ16K	24
PT-JW130H*4	71	PT-MZ17K	23
PT-JX200F*4	70	PT-MZ20K	23
PT-JX200G*4	70	PT-MZ570	26
PT-JX200H*4	70	PT-MZ670	26
PT-LB1	69	PT-MZ680	25
PT-LB1V	69	PT-MZ682*4	25
PT-LB2	69	PT-MZ770	26
PT-LB2V	69	PT-MZ780	25
PT-LB3	69	PT-MZ782	25
PT-LB330	66	PT-MZ880	25

PT-MZ882	25	PT-RZ990*4	15
PT-RCQ10	14	PT-ST10	69
PT-RCQ80	14	PT-TMW380	28
PT-REQ10	11	PT-TMX380	28
PT-REQ12	11	PT-TMZ400	28
PT-REQ15	11	PT-TW230	67
PT-REQ80*4	11	PT-TW231R	67
PT-REZ10	11	PT-TW250*4	66
PT-REZ12	11	PT-TW340*4	66
PT-REZ15	11	PT-TW341R	66
PT-REZ80	11	PT-TW342*4	66
PT-RQ13K	10	PT-TW343R	66
PT-RQ18K	8	PT-TW350*4	65
PT-RQ22K	13	PT-TW351R	65
PT-RQ25K	8	PT-TW370*4	64
PT-RQ32K	9	PT-TW371R	64
PT-RQ35K	7	PT-TW380*4	63
PT-RQ50K	6	PT-TW381R	63
PT-RQ6	11	PT-TX310*4	66
PT-RQ7	11	PT-TX312*4	66
PT-RS11K	10	PT-TX320*4	65
PT-RS20K	13	PT-TX340*4	64
PT-RS30K	9	PT-TX350*4	63
PT-RW330	33	PT-TX400*4	66
PT-RW430	32	PT-TX402*4	66
PT-RW620	16	PT-TX410*4	65
PT-RW630	17	PT-TX430*4	64
PT-RW730	16	PT-TX440*4	63
PT-RW930	16	PT-VMW50	29
PT-RX110	16	PT-VMW51	27
PT-RZ12K	10	PT-VMW60*4	29
PT-RZ120	14	PT-VMW61*4	27
PT-RZ14K	8	PT-VMZ40*4	29
PT-RZ16K	12	PT-VMZ41*4	27
PT-RZ17K	8	PT-VMZ50	29
PT-RZ21K	13	PT-VMZ51	27
PT-RZ24K	8	PT-VMZ51S*4	27
PT-RZ31K	9	PT-VMZ60	29
PT-RZ34K	7	PT-VMZ61	27
PT-RZ370	33	PT-VMZ71	27
PT-RZ470	32	PT-VW330	53
PT-RZ475	31	PT-VW340*4	56
PT-RZ570	30	PT-VW345N	48
PT-RZ575	30	PT-VW350*4	56
PT-RZ6	11	PT-VW355N	48
PT-RZ660	16	PT-VW360	55
PT-RZ670	17	PT-VW430	52
PT-RZ690	15	PT-VW431D	52
PT-RZ7*4	11	PT-VW435N	54
PT-RZ770	16	PT-VW440	52
PT-RZ790*4	15	PT-VW530*4	50
PT-RZ870	17	PT-VW535N	48
PT-RZ890	15	PT-VW540*4	49
PT-RZ970	16	PT-VW545N	47

PT-VX400	53
PT-VX400NT	54
PT-VX405*4	52
PT-VX406*4	57
PT-VX41	53
PT-VX410*4	56
PT-VX415N	48
PT-VX42*4	56
PT-VX420*4	56
PT-VX421*4	57
PT-VX425N	48
PT-VX430	55
PT-VX431K	55
PT-VX45*4	52
PT-VX46*4	57
PT-VX50*4	50
PT-VX500	52
PT-VX501*4	52
PT-VX505N	54
PT-VX51*4	49
PT-VX510	52
PT-VX60*4	50
PT-VX600*4	50
PT-VX605N	48
PT-VX61*4	49
PT-VX610	49
PT-VX615N	47
PT-VZ470*4	51
PT-VZ570*4	50
PT-VZ575N	48
PT-VZ580*4	49
PT-VZ585N	47
TH-D10000	39
TH-D3500	41
TH-D5600	41
TH-D7700	40
TH-DW10000	39
TH-DW5000	41
TH-DW7000	40

*1: Note on model groups

The difference in the type of information that can be accessed for “rich information models” and “basic information models” is as follows.

○: Supported ×: Not supported

Item	Model categorization based on accessible information difference	
	Rich information model	Basic information model
Group Name	○	○
IP Address	○	○
Shutter (AV Mute)	○	○
Model Name	○	○
Serial Number	○*	×
Selected input	○	○
Power	○	○
Selected LIGHT	○*	×
LIGHT Power / Operating mode	○	×
Signal Freq.	○	×
Main Version	○	×
Network Version	○*	×
Power on hours	○	○*
Temperature	○*	×
LIGHT status	○*	○*
Fan status	○*	×

* May not be accessible depending on the device.

*2: Model number of product sold in Japan. This will differ for products sold in other regions.

*3: Model number of product sold in regions other than Japan. This will differ for products sold in Japan.

*4: Not sold in Japan.

Notes

The software is not compatible with any device models not appearing in this “Device model list.”

Peripheral device list

■ Peripheral devices

Media Processor FMP Series

ET-FMP50	72	ET-SBFMP10	72
ET-FMP20	72		

Network camera

Panasonic BB-S Series, DG-S Series, WV-S Series, AW-UN70 Series, AW-HN130 Series, AW-HN40 Series, AW-HE130 Series, AW-HE40 Series, and AW-HR140 network cameras are supported. Allows the video shown on a display (projector or flat-panel display) to be checked remotely through a camera.

PT-RQ50K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/X/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	@Panasonic* ²
	PJLink	Password	@Panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	○	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-RQ35K / PT-RZ34K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	×	
Push notification function	○		

*1: The username and password of the administrator account must be configured.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/EJ/X/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	○	
Push notification function	○		

*1: The username and password of the administrator account must be configured.

PT-RQ32K / PT-RZ31K / PT-RS30K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
Standby mode	Normal		
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	○* ³	
Push notification function	○* ⁴		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: The PT-RS30K does not support the simultaneous multi-device firmware update function.

*4: The PT-RS30K does not support error information push notification.

PT-RQ13K / PT-RZ12K / PT-RS11K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-REQ15 / PT-REQ12 / PT-REQ10 / PT-REQ80

■ PT-REZ15 / PT-REZ12 / PT-REZ10 / PT-REZ80

■ PT-RQ7 / PT-RQ6 / PT-RZ7 / PT-RZ6

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/EJ/J/UG/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	○	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	○	
	Push notification function	○	

*1: The username and password of the administrator account must be configured.

PT-RZ16K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
PJLink	Password	Set by user* ¹	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
Standby mode	Normal		
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	○	
	Push notification function	○	

*1: The username and password of the administrator account must be configured.

PT-RQ22K / PT-RZ21K / PT-RS20K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	@Panasonic* ²
	PJLink	Password	@Panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	○* ³	
Push notification function	○* ⁴		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: The PT-RS20K does not support the simultaneous multi-device firmware update function.

*4: The PT-RS20K does not support error information push notification.

PT-RCQ10 / PT-RCQ80

PT-RZ120

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/X/(blank), lens: (blank)/L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin*1
		Password	@Panasonic*2
PJLink	Password	@Panasonic*2	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	○	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-RZ990 / PT-RZ890 / PT-RZ790 / PT-RZ690

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/(blank), lens: (blank)/L, cabinet color: B/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: The username and password of the administrator account must be configured.

PT-RZ970 / PT-RW930 / PT-RX110 / PT-RZ770 / PT-RW730 / PT-RZ660 / PT-RW620

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-FRQ60

■ PT-FRQ50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
PJLink	Password	Set by user* ¹	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: The username and password of the administrator account must be configured.

PT-FRZ60 / PT-FRZ50 / PT-FRZ55

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: The username and password of the administrator account must be configured.

PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-DZ21K / PT-DS20K / PT-DW17K / PT-DZ16K

■ PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
PJLink	Password	panasonic*2	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/E/J/T/U/(blank), lens: (blank)/L, cabinet color: B/K/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-MZ20K / PT-MZ17K / PT-MZ14K / PT-MZ11K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/EJ/JX/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	○	
	Simultaneous multi-device firmware update function	○	
Push notification function	○		

*1: The username and password of the administrator account must be configured.

PT-MZ16K / PT-MZ13K / PT-MZ10K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/J/X/(blank), lens: L, cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	@Panasonic* ²
	PJLink	Password	@Panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-MZ882 / PT-MZ782 / PT-MZ682

■ PT-MZ880 / PT-MZ780 / PT-MZ680

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
PJLink	Password	Set by user* ¹	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	○	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: The username and password of the administrator account must be configured.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/J/(blank), lens: (blank)/L, cabinet color: (blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin*1
		Password	@Panasonic*2
	PJLink	Password	@Panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	○	
	Wireless settings display function	○*3	
	DATA CLONING	○	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: Optional wireless module (ET-WM300) is required.

PT-VMZ71 / PT-VMZ61 / PT-VMZ51 / PT-VMZ51S / PT-VMZ41 / PT-VMW61 / PT-VMW51
PT-CMZ50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: The username and password of the administrator account must be configured.

PT-LMZ460 / PT-LMZ420 / PT-LMW460 / PT-LMW420 / PT-LMX460 / PT-LMX420 / PT-TMZ400 / PT-TMW380 / PT-TMX380

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: The username and password of the administrator account must be configured.

PT-VMZ60 / PT-VMZ50 / PT-VMZ40 / PT-VMW60 / PT-VMW50

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank), cabinet color: B/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	@Panasonic* ²
	PJLink	Password	@Panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-RZ575 / PT-RZ570

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/J/T/(blank), cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-RZ475

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○* ³	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.

PT-RZ470 / PT-RW430

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank), cabinet color: K/W/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○*3	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: If the temperature of the projector's surroundings is elevated, light output may be reduced in order to protect the projector unit. If this software is used for the brightness control of multiple projectors, please ensure that as far as possible the temperature of the surroundings is the same for all projectors.

PT-RZ370 / PT-RW330

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-DZ12000 / PT-D12000 / PT-DW100

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not required (LAN terminal installed)*1	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*2
		Password	panasonic*3
PJLink	Password	panasonic*3	
Projector settings	Network standby	ON	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	1024	
	PJLink control	ON	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.

With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).

The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported.

*2: This is the user name provided at the time of shipment.

*3: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-DZ8700 / PT-DS8500 / PT-DW8300 / PT-DZ110XE / PT-DS100XE / PT-DW90XE / PT-DW105XEA

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	○	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-DZ6710 / PT-DZ6700 / PT-DW6300 / PT-D6000 / PT-D5000

■ PT-DW730 / PT-DX800

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank), cabinet color: K/S/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
PJLink	Password	panasonic*2	
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-DZ570 / PT-DW530 / PT-DX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

TH-DW10000 / TH-D10000 / PT-DW10000 / PT-D10000

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not required (LAN terminal installed)*1	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	user1
		Password	panasonic*2
PJLink	Password	panasonic*2	
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: Of the commercially available expansion boards, the ET-MD77NT network board is not supported.

With expansion boards other than the ET-MD77NT, the network function on the expansion board side cannot be used (DVI, SDI, and other inputs are enabled).

The ET-MD100SD4 digital signal input board (for dual link HD-SDI) is supported. (except for TH-D10000 and PT-D10000)

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

TH-D7700 / TH-DW7000 / PT-D7700 / PT-DW7000

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U, cabinet color: K/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Expansion board required*1	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	user1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: One of the following commercially available expansion boards with a network function is required.

Network board: ET-MD77NT

Digital signal input board (for SD-SDI): ET-MD77SD1

Digital signal input board (for HD-SDI): ET-MD77SD3

Digital signal input board (for DVI): ET-MD77DV

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-D5700 / PT-D4000 / PT-DW5100

■ TH-D5600 / PT-D5600 / TH-DW5000 / PT-DW5000

■ TH-D3500 / PT-D3500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	user1
		Password	panasonic*1
	PJLink	Password	panasonic*1
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-EZ770 / PT-EW730 / PT-EX800

■ PT-EZ580 / PT-EW640 / PT-EW540 / PT-EX610 / PT-EX510

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: A/D/J/K/T/Z/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-EZ590 / PT-EW650 / PT-EW550 / PT-EX620 / PT-EX520 / PT-EZ57

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-EZ591 / PT-EW651 / PT-EW551 / PT-EX621 / PT-EX521

■ PT-FZ570 / PT-FW530 / PT-FX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/K/T/(blank), lens: (blank)/L)

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-EZ570 / PT-EW630 / PT-EW530 / PT-EX600 / PT-EX500

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal, Network	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-EX16K **PT-EX12K**

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-VZ585N / PT-VW545N / PT-VX615N

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	Normal		
	Standby mode	—	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	○	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-VZ575N / PT-VW535N / PT-VX605N

■ PT-VW355N / PT-VX425N

■ PT-VW345N / PT-VX415N

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	○	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-VZ580 / PT-VW540 / PT-VX610 / PT-VX61 / PT-VX51

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/K/K1/T/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	ON	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/T/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-VZ470

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-VW440 / PT-VX510

■ PT-VW431D

■ PT-VW430 / PT-VX501 / PT-VX500 / PT-VX405 / PT-VX45

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1* ¹
		Password	panasonic* ²
	PJLink	Password	panasonic* ²
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	Command control	—
		WEB port / Command port	—
	PJLink control	PJLink control	—
		ECO management	
	Standby mode	Standby mode	—
		Standby mode	Network
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/KEA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Network	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Network	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-VW360 / PT-VX430 / PT-VX431K

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	@Panasonic* ²
	PJLink	Password	@Panasonic* ²
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/EA/J/T/Z/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-FW430 / PT-FX400

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-FW300NT / PT-FW300 / PT-F300NT / PT-F300

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	ON	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-FW100NT / PT-F100NT

■ PT-F200NT

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	user1
		Password	No password set* ¹
	PJLink	Password	No password set* ¹
Projector settings	Network standby	ON	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
Standby mode	—		
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	×	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the setting provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-LZ370

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-LRZ35 / PT-LRW35

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: U/(blank))

Model group: **Basic information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	dispadmin* ¹
		Password	Set by user* ¹
	PJLink	Password	Set by user* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	X	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: The username and password of the administrator account must be configured.

■ PT-LB426 / PT-LB386 / PT-LB356 / PT-LW376 / PT-LW336

■ PT-TW381R / PT-TW380 / PT-TX440 / PT-TX350

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/T/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	Set by user* ¹
		Password	Set by user* ¹
PJLink	Password	Set by user* ¹	
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: The username and password of the administrator account must be configured.

■ PT-LW375 / PT-LW335 / PT-LB425 / PT-LB385 / PT-LB355

■ PT-TW371R / PT-TW370 / PT-TX430 / PT-TX340

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/K/T/U/(blank))

Model group: **Basic information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin
		Password	admin1* ¹
	PJLink	Password	admin1* ¹
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	X	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-LW373 / PT-LW333 / PT-LB423 / PT-LB383 / PT-LB353

■ PT-TW351R / PT-TW350 / PT-TX410 / PT-TX320

■ PT-LW362 / PT-LW312 / PT-LB412 / PT-LB382 / PT-LB332

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin
		Password	admin1* ¹
	PJLink	Password	admin1* ¹
Projector settings	Network standby	—	
	Network control	WEB control	—
		Command control	—
		WEB port / Command port	—
		PJLink control	—
		ECO management	
	Standby mode	—	
Standby mode	Normal		
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	X	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

■ PT-LW330*2 / PT-LW280*2 / PT-LB360*2 / PT-LB330*2

■ PT-TW343R / PT-TW342 / PT-TX402 / PT-TX312

■ PT-TW341R*2 / PT-TW340*2 / PT-TW250*2 / PT-TX400*2 / PT-TX310*2

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/J/(blank))

Model group: **Basic information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin
		Password	admin1*1
	PJLink	Password	admin1*1
Projector settings	Network standby	—	
	Network control		
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
Standby mode	—		
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	X	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	X	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
Push notification function	X		

*1: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*2: Only devices with serial numbers that start with "B" or "DB53" are supported.

■ PT-LW25H / PT-LX30H / PT-LX26H

■ PT-TW231R / PT-TW230

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported X: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Network	
Monitoring and control functions	Auto search (local network) function	X	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	X	
	ECO management function	X	
	Maintenance log save function	○	
	Contents list delivery function	X	
	Wireless settings display function	X	
	DATA CLONING	X	
	Remote preview function or remote preview lite	X	
	Simultaneous multi-device firmware update function	X	
	Push notification function	X	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-LB90NT

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

PT-LB3 / PT-LB2V / PT-LB2 / PT-LB1V / PT-LB1 / PT-ST10

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: E/EA/U/(blank))

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control	ON	
	WEB control	—	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	—	
	ECO management		
	Standby mode	—	
	Standby mode	Normal	
Monitoring and control functions	Auto search (local network) function	×	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	×	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	×	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal*3	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	○	
	Contents list delivery function	×	
	Wireless settings display function	○	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
	Push notification function	×	

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

* Alphabet letters at end (place of destination: D/E/K/T/U, cabinet color: B/W)

Model group: **Rich information model**

○: Supported ×: Not supported —: Not available

		Setting / compatibility	
Optional accessories	Expansion boards	Not used	
Connection to projector	IP address	Only fixed IP address supported	
	WEB control screen login	User name	admin1*1
		Password	panasonic*2
	PJLink	Password	panasonic*2
Projector settings	Network standby	—	
	Network control		
	WEB control	ON	
	Command control	—	
	WEB port / Command port	—	
	PJLink control	ON	
	ECO management		
Standby mode	—		
	Standby mode	Normal*3	
Monitoring and control functions	Auto search (local network) function	○	
	Device status monitoring function (Simplified)	○	
	Device location information registering function (Map monitoring function)	○	
	Command transmission function	○	
	Brightness control function	×	
	ECO management function	○	
	Maintenance log save function	×	
	Contents list delivery function	×	
	Wireless settings display function	○	
	DATA CLONING	×	
	Remote preview function or remote preview lite	×	
	Simultaneous multi-device firmware update function	×	
Push notification function	×		

*1: This is the user name provided at the time of shipment.

*2: This is the password provided at the time of shipment. Use the same password as for WEB control of the projector unit.

*3: When set to “Network” or “ECO”, information acquisition and control will be disabled.

ET-FMP50 / ET-FMP20 / ET-SBFMP10

The letters* that appear at the end of the above model numbers are omitted, as they are not relevant to feature availability.

○: Supported ×: Not supported —: Not available

		Setting / compatibility
Connection to Media Processor	IP address	Only fixed IP address supported
	User name	Set by user* ¹
	Password	Set by user* ¹
Functions	Media Processor power status display	○
	WEB control screen display	○
	Serial number display	○

*1: The username and password of the account must be configured.