



| No. | Part Name                    | Material                     | Process-Remark |
|-----|------------------------------|------------------------------|----------------|
| 1   | Network Camera Unit          | -                            |                |
| 2   | Cover Top                    | ABS Resin                    | Coating(Black) |
| 3   | Cover Front                  | ABS Resin                    | Coating(Black) |
| 4   | Cover Rear                   | ABS Resin                    | Coating(Black) |
| 5   | Camera Case                  | ABS Resin                    | Printing       |
| 6   | Camera Case Bottom           | ABS Resin                    |                |
| 7   | SD Memory Card Cover         | ABS Resin                    |                |
| 8   | Lock Plate                   | Aluminium Alloy              |                |
| 9   | Camera Mount Plate           | Carbon Steel                 |                |
| 10  | Name Plate                   | Polyester Film               | Printing       |
| 11  | Safety Wire Hook             | Carbon Steel/Stainless Steel |                |
| 12  | Decorative Cover Lower       | ABS Resin                    | Printing       |
| 13  | Decorative Cover Upper       | ABS Resin                    |                |
| 14  | Base Mount Plate             | Carbon Steel/Stainless Steel |                |
| 15  | Safety Wire                  | Stainless Steel              |                |
| 16  | Camera Fixing Screw          | Carbon Steel M3              | Plating        |
| 17  | Network Connector            | -                            |                |
| 18  | Status Indicator             | -                            |                |
| 19  | 12V DC Power Supply Terminal | -                            |                |
| 20  | EXT I/O Terminal             | -                            |                |
| 21  | Audio Input Connector        | -                            |                |
| 22  | Audio Output Connector       | -                            |                |
| 23  | INITIAL SET Button           | -                            |                |
| 24  | SD Memory Card Slot          | -                            |                |
| 25  | SD ON/OFF Button             | -                            |                |
| 26  | SD MOUNT Indicator           | -                            |                |
| 27  | Code Label                   | Polyester Film               | Printing       |
| 28  | Certification label          | Polyester Film               | Printing       |
| 29  | Cover Set Label              | Polyester Film               | Printing       |
| 30  | FCC/DOC Label                | Polyester Film               | Printing       |
| 31  | CE Label                     | Polyester Film               | Printing       |
| 32  | VCCI Label                   | Polyester Film               | Printing       |
| 33  | Serial No. Label             | Polyester Film               | Printing       |
| 34  | AUX Label                    | Polyester Film               | Printing       |